


BIC Models 911, 912, 912C, 914 and 914C
Part number may change. When ordering parts indicate model number, part number and description.

Official Parts List | B·i·C Models 911, 912, 912C, 914 and 914C

REF. NO.	911 PART NO.	912 PART NO.	912C PART NO.	914 PART NO.	914C PART NO.	DESCRIPTION
1	—	—	37-143-01	—	37-143-01	T/T "c" clip
2	37-302-01	37-302-01	37-267-01	37-302-01	37-267-01	T/T mat
3	10-366-02	10-366-02	38-385-01	—	38-385-01	Trim ring-ssn (not shown)
4	37-130-01	37-130-01	38-180-01	10-366-02	37-130-01	Trim ring-ig (not shown)
5	—	—	10-318-01	37-130-01	10-318-01	Drive belt
6	10-319-01	—	20-060-01	—	20-060-01	Record support
7	20-060-01	20-060-01	10-319-01	20-060-01	10-319-01	Set screw
8	38-159-01	38-161-01	38-160-01	38-161-02	38-160-02	Control escutcheon insert
9	38-162-02	38-162-01	38-162-01	38-162-01	38-162-01	Trim—play key
10	10-393-02	10-393-01	10-393-01	10-393-01	10-393-01	Play key w/trim
11	10-370-01	10-370-01	10-370-01	10-382-01	10-382-01	Counterbalance wgt.
12	37-268-02	37-268-01	37-268-01	37-268-02	37-268-01	T/A slot cover
13	10-322-07	10-322-07	10-322-06	10-322-07	10-322-06	Top trim
14	37-251-01	37-251-01	37-251-01	37-251-01	37-251-01	Lens, anti-skate
15	10-368-01	10-368-01	10-368-01	—	—	Pivot pin—fixed
16	10-369-01	10-369-01	10-369-01	—	—	Gimbal
17	38-155-01	38-155-01	38-155-01	—	—	Trim—gimbal (not shown)
18	10-367-01	10-367-01	10-367-01	—	—	Pivot pin—floating
19	37-309-01	37-309-01	37-309-01	40-257-01	40-257-01	Plug—T/A tube
20	10-327-01	10-327-01	10-327-01	—	—	Pivot (2)
21	20-484-01	20-484-01	20-484-01	—	—	Screw (2)
22	37-254-01	37-254-01	37-254-01	—	—	Pivot block
23	38-037-01	38-146-01	38-146-01	—	—	Trim—pivot blk (not shown)
24	10-321-01	10-321-01	10-321-01	—	—	T/A complete (nos. 16-30)
25	20-268-01	20-268-01	20-268-01	—	—	Harness
26	10-372-02	10-372-02	10-372-02	—	—	Screw
27	39-220-01	39-220-01	39-220-01	—	—	Head shell assy.
28	22-027-01	22-027-01	22-027-01	—	—	(nos. 26, 27, 29, 30)
29	23-256-01	23-256-01	23-256-01	—	—	Bkt mtg. screw
30	20-063-01	20-063-01	20-063-01	—	—	Washer (not shown)
31	10-419-01	10-419-01	10-419-01	—	—	"c" clip (not shown)
32	21-005-01	21-005-01	21-005-01	—	—	Washer
33	22-007-01	22-007-01	22-007-01	—	—	Bkt. mtg. Bkt. & nut assy.
34	39-172-01	39-172-01	39-172-02	37-250-01	37-250-01	Hex nut
35	20-263-01	20-263-01	20-263-01	39-172-02	39-172-02	Bearing
36	36-025-02	36-025-02	36-025-02	20-263-01	20-263-01	Washer (as required)
37	23-525-01	23-525-01	23-525-01	39-172-02	39-172-02	Cue rate knob
38	40-257-01	40-257-01	40-257-01	20-263-01	20-263-01	Cylinder—lift pin
39	22-343-01	22-343-01	22-343-01	36-025-01	36-025-01	P/U hgt. adj. screw
40	23-543-01	23-543-01	23-543-01	40-257-01	40-257-01	P/U base
41	39-139-01	39-139-01	39-139-01	22-343-01	22-343-01	"c" clip
42	40-493-01	40-493-01	40-493-01	23-543-01	23-543-01	Spring—brake rod
43	10-062-02	10-062-02	10-062-02	39-139-01	39-139-01	Washer—brake rod
44	38-563-01	38-563-01	38-563-01	10-062-02	10-062-02	"c" clip—brake rod
45	22-003-01	22-003-01	22-003-01	38-563-01	38-563-01	brake rod
46	40-258-01	40-258-01	40-258-01	22-003-01	22-003-01	Spring—brake bias
47	39-369-01	39-369-01	39-369-01	40-258-01	40-258-01	Lift pin & pivot assy.
48	40-035-01	40-035-01	40-035-01	39-369-01	39-369-01	Rocker plate
49	37-294-02	37-294-02	37-294-01	40-035-01	40-035-01	Washer—rocker plate
50	21-282-01	21-282-01	21-282-01	37-294-02	37-294-01	Spring—rocker plate
51	38-171-01	38-171-01	38-171-01	21-282-01	21-282-01	Screw w/locking
				38-171-01	38-171-01	Return spring
						Patnut (2)
						Trim—strobe window

Official Parts List | B·i·C Models 911, 912, 912C, 914 and 914C (Continued)

REF. NO.	911 PART NO.	912 PART NO.	912C PART NO.	914 PART NO.	914C PART NO.	DESCRIPTION
110	—	41-015-01	41-015-01	41-015-01	41-015-01	Reject rod
111	38-122-01	40-286-01	40-286-01	40-286-01	40-286-01	Spring—reject rod
112	20-268-02	38-122-01	38-122-01	38-122-01	38-122-01	Gue link
113	38-122-01	20-268-02	20-268-02	38-122-01	38-122-01	Screw—cue link
114	37-205-01	37-205-01	37-205-01	37-205-01	37-205-01	Spring—cue link
115	37-204-01	37-204-01	37-204-01	37-204-01	37-204-01	Cue mounting Bkt.
116	20-013-02	20-013-02	20-013-02	20-013-02	20-013-02	Cue spool
117	20-187-01	20-187-01	20-187-01	20-187-01	20-187-01	Screw
118	20-064-01	20-064-01	20-064-01	20-064-01	20-064-01	Screw
119	36-045-01	36-045-01	36-045-01	36-045-01	36-045-01	Screw
120	36-045-01	36-045-01	36-045-01	36-045-01	36-045-01	Screw
121	40-032-01	40-032-01	40-032-01	40-032-01	40-032-01	Cue lever
122	37-199-02	37-199-02	37-199-02	37-199-02	37-199-02	Spring—program plate
123	37-198-02	37-198-02	37-198-02	37-198-02	37-198-02	Spring—secondary plate
124	17-567-02	17-567-02	17-567-02	17-567-02	17-567-02	Secondary program plate
125	40-564-01	40-564-01	40-564-01	40-564-01	40-564-01	Program plate
126	38-137-01	40-286-01	40-286-01	38-137-01	38-137-01	Sleeve
127	40-286-01	10-309-01	10-309-01	40-286-01	40-286-01	Spring—stop lever
128	10-309-01	40-286-01	40-286-01	10-309-01	10-309-01	Slop lever
129	40-283-01	40-283-01	40-283-01	40-283-01	40-283-01	Spring size selector lever
130	23-292-01	23-292-01	23-292-01	23-292-01	23-292-01	Size selector lever
131	37-265-01	37-265-01	37-265-01	37-265-01	37-265-01	Spring—compression
132	10-307-01	10-307-01	10-307-01	10-307-01	10-307-01	"c" clip
133	38-541-01	38-541-01	38-541-01	38-541-01	38-541-01	Drive plate bracket
134	22-560-01	22-560-01	22-560-01	22-560-01	22-560-01	Drive plate
135	40-155-01	40-155-01	40-155-01	40-155-01	40-155-01	Bias plate
136	23-292-01	23-292-01	23-292-01	23-292-01	23-292-01	Fibre washer
137	40-032-01	40-032-01	40-032-01	40-032-01	40-032-01	Spring—override
138	40-371-01	40-371-01	40-371-01	40-371-01	40-371-01	"c" clip
139	10-386-01	10-386-01	10-386-01	10-386-01	10-386-01	Spring—drive plate
140	20-181-01	20-181-01	20-181-01	20-181-01	20-181-01	Line cord
141	10-320-01	10-320-01	10-320-01	10-320-01	10-320-01	Screw
142	20-293-03	20-293-03	20-293-03	20-293-03	20-293-03	Photo socket
143	39-227-01	39-227-01	39-227-01	39-227-01	39-227-01	Screw
144	10-420-01	10-420-01	10-420-01	10-420-01	10-420-01	Photo socket
145	39-144-01	39-144-01	39-144-01	39-144-01	39-144-01	Nut—VIA foot (4)
146	23-180-01	23-180-01	23-180-01	23-180-01	23-180-01	VIA foot (4)
147	22-023-01	22-023-01	22-023-01	22-023-01	22-023-01	Transit screw (4)
148	37-182-01	37-182-01	37-182-01	37-182-01	37-182-01	"c" clip (4)
149	37-188-01	37-188-01	37-188-01	37-188-01	37-188-01	Washer (4)
150	21-280-01	21-280-01	21-280-01	21-280-01	21-280-01	Grommet (4)
151	10-316-01	10-316-01	10-316-01	10-316-01	10-316-01	Rate adjuster
152	37-278-01	37-278-01	37-278-01	37-278-01	37-278-01	Nut
153	20-293-02	20-293-02	20-293-02	20-293-02	20-293-02	VIA spring assy.
154	22-012-01	22-012-01	22-012-01	22-012-01	22-012-01	Mounting block
155	20-047-01	20-047-01	20-047-01	20-047-01	20-047-01	Screw
156	20-268-02	20-268-02	20-268-02	20-268-02	20-268-02	Washer
157	20-187-01	20-187-01	20-187-01	20-187-01	20-187-01	Screw—VIA wheel
158	27-030-01	27-030-01	27-030-01	27-030-01	27-030-01	Screw—reflector Bkt.
159	12-057-04	12-057-04	12-057-04	12-057-04	12-057-04	Screw—reflector Bkt.
160	38-201-01	38-201-01	38-201-01	38-201-01	38-201-01	Play key w/trim
161	37-258-01	37-258-01	37-258-01	37-258-01	37-258-01	Counterbalance wgt.
162	23-180-01	23-180-01	23-180-01	23-180-01	23-180-01	T/A complete (nos. 16-30)
163	28-192-01	28-192-01	28-192-01	28-192-01	28-192-01	Harness
164	21-280-01	21-280-01	21-280-01	21-280-01	21-280-01	Screw
165	14-374-01	14-374-01	14-374-01	14-374-01	14-374-01	Head shell assy.
166	12-043-02	12-043-02	12-043-02	12-043-02	12-043-02	(nos. 26, 27, 29, 30)



BIC Models 916MP | 916MPC

Part numbers may change. When ordering parts indicate model number, part number and description.